

# How to Measure Your Window Wells

**ILWindowWellCover.com**

**1-708-567-7616**

## STEP 1

Determine **shape** of well

**Rounded?**

**Squared?**



## STEP 2

### Measure Width

Measure the widest horizontal distance from outside edge to outside edge



## STEP 3

### Measure Projection

Measure from the exterior wall of the house straight out to the furthest edge of the window well



## STEP 4

### Window Height

If window comes above window well. Measure from top of window to top of window well.



## STEP 5

### Take Photos

Take a straight down photo of window well and any obstructions



**Scan to fill out Estimate Form**



**ICC ILLINOIS WINDOW WELL COVER COMPANY**